



# ASTRA INDUSTRIES SAL

## NOTICE

### ASTRA ARL 4x8 Watts LED

#### INSTALLATION NOTICE (English)

- This fitting is installed “lay on”, a false ceiling of 60 x 60 cm opening no special fixing is needed or tools (Picture 1)
- Previously, the AC current must be plugged to the connector at the back of the fitting. (Picture 2)
- Make a primary test to the AC current (110-240 volts 50-60 Hz)

#### Caution:

- It is imperative to plug this fitting to the earth line.
- This electronic device is intended to be installed in the false ceiling by professional only.
- Do not put on and of the current very quickly, it is an electronic device.
- Do not arc weld on the same AC line
- All maintenance operation must be made by a technician.
- Keep 2 cm space above the heat sink on the top of the fitting
- Ensure driver has not been powered for at least 1 min before connecting LED string
- Do not invert red and black wires low voltage from the driver to the diode
- Keep away from the acetic acid (Acetic acid is vinegar and several glues in the market, or silicone contain this material)
- Maintenance free: this fitting do not require any special maintenance , use dry towel for cleaning and only ethylic alcohol for the LED

#### Warranty

- This fitting is warranted for two years for the diode and 6 months for the Constant Current Driver. On condition that the installation is correct.



PICTURE 1



PICTURE 2